


Diagnostics and user statistics

- The system permits function checks of the following parameters in the sequence shown (diagnostic mode):
 - Solenoid valve function check
 - Battery function check/capacity
 - Sensor function check/sensor field

To call up diagnostics mode, press the lower button for at least 5 seconds.



- The user statistics indicate the number of uses per day for the preceding 30 days. To call up the statistics mode, press the upper button for at least 5 seconds.

